SonicCell System program (Ver.1.04)
2007 AUGUST (C) Roland Corporation
This System Program Update will update your SonicCell's system program to the latest version.

__ Changes _____

Ver.1.02 to Ver.1.04

[Changes]

Display of the Patch Names
We have fixed a problem to correctly display the GM Patch List.

Song Start by MIDI
When the Sync Mode is set to SLAVE, we have fixed a problem to prevent the playback of the demo song when it receives a MIDI Start message.

USB Interface
We have fixed the problem that caused noise to be briefly heard in the USB audio on rare occasions.
We have improved the processing of large amounts of data received via USB-MIDI.

Audio Player
We have fixed the problem in which short WAV/AIFF files approximately five seconds long would fail to play back correctly on rare occasions.

Demo Playback
After the fourth demo song has finished playing, it will now return to the beginning of the first song and stop.

Screen Saver Function
The screen saver function will now work in the Song Play screen.

__ Items required for updating the SonicCell _____

- The SonicCell itself
- A USB memory
- A computer with USB port
- The update file (sonic_cell_up.bin)

__ Checking the version _____

Check the version of your SonicCell before you update.

1. Turn the power of SonicCell on.
2. Press [MENU] button to call the MENU screen.
3. Turn [CURSOR/VALUE] to select Version Info screen.

* If your SonicCell already has the latest software version, you don't need to update.

__ Cautions when updating (Important!) _____

Don't use this system program for any product other than the SonicCell. Doing so may damage the data or system of your other product.

We recommend that you save your user data before you perform the update. If a problem occurs and your user data is lost, you will be able to restore the original state by reloading the data you saved. For details on the procedure, refer the Owner's Manual (p.182).

Do not power-off the SonicCell while the update is in progress. If the power should accidentally fail during the update, the SonicCell system will be damaged, and the unit may become inoperable.

We regret that we cannot answer questions regarding the procedure of installing this system program. You must perform the installation on your own responsibility, in accordance with the information provided in this document.

__ Update procedure _____

Update procedure

1. Place sonic_cell_up.bin in the root directory of your USB memory on your computer.
2. Connect the USB memory to the SonicCell, and turn on the power.
3. When you turn on the power, loading will begin and the ACCESS LED will start blinking.
4. When the "Completed" message appears, the update is complete.
5. Turn off the power and remove the USB memory, then turn on the power for normal operation again.

__ Other notices _____

Unauthorized modification of these files, transfer to another network, or inclusion with a magazine or commercial product is prohibited.

Roland Corporation disclaims all responsibility for any damages (including but not limited to loss of profit, loss of data, or any financial loss) that may result from the use of or inability to use this software. This disclaimer applies even if Roland Corporation had been previously advised of the possibility of such damages.

Trademarks and registered trademarks in this document are the property of their respective owners.